

XD-S™ POINTS OF LUBRICANT

NOTE: Please read entire manual and follow all safety rules before handling firearm.

1. Field Strip pistol. Only remove slide from frame (See page 23).
2. Using any quality firearm lubricant, 1 drop of lubricant on each side of the rear slide railways (See Figure 30-1).
3. Reassemble slide to frame (See page 26).
4. Manipulate slide back and forth 5 - 10 times.
5. 1 drop of lubricant on top of chamber area of the barrel (See Figure 30-2).
6. Lock slide to the rear.
7. 1 drop of lubricant on the top of the muzzle of the barrel, 1/4" from front top of muzzle (See Figure 30-3).
8. Manipulate slide back and forth 5 - 10 times.



Figure 30-1



Figure 30-2



Figure 30-3